

## Waste Acceptance Procedure

All commercial waste deliveries are weighed at the weighbridge and the relevant documentation (e.g. Waste Collection Permits) is checked. Any waste delivery vehicle that does not have the appropriate documentation is not accepted. After the weighbridge the vehicles are directed into the Main Processing Building where the wastes are off loaded and inspected.

Any unsuitable materials, for example batteries, are immediately removed to the waste quarantine area, located at the northern side of the Garage where it is stored pending consignment to the producer or an appropriate treatment/disposal facility. AES maintain records of the waste type, quantity, and ultimate disposal/treatment facility.

On the floor of the Main Processing Building the potential recyclables are mechanically segregated using a large track machine with a hydraulic arm into individual waste groups such as dry recyclables, metals, inert (C&D waste) and biodegradable waste. These materials are stored inside the building pending consignment for further treatment/disposal. The mixed municipal solid wastes are bulked up for onward transfer.

For inspection purposes only.  
Consent of copyright owner required for any other use.