

For inspection purposes only.
Consent of copyright owner required for any other use.

Section	How the BAT requirements will be met at the O'Toole Composting Ltd.		
	Aspect	BAT	How the BAT requirements will be met at the composting facility
Tank Design			
Section 5.1 Storage of Liquids and Liquefied Gases Section 5.1.1 Tanks	Section 5.1.1.1 General Principles to prevent and reduce emissions	BAT for a proper design is to take into account at least the following: <ul style="list-style-type: none"> • The physico-chemical properties of the substance being stored • How the storage is operated, what level of instrumentation is needed, how many operators are required, and what their workload will be • How the operators are informed of deviations from normal process conditions (alarms) • How the storage is protected against deviations from normal process conditions (safety instructions, interlock systems, pressure relief devices, leak detection and containment, etc.) • What equipment has to be installed, largely taking account of past experiences of the product (construction materials, valve quality, etc.) • Which maintenance and inspection plan needs to be implemented and how to ease the maintenance and inspection work (access, layout, etc.) • How to deal with emergency situations (distances to other tanks, facilities and to the boundary, fire protection, access for emergency services such as the fire brigade, etc.). See annex 8.19 for a typical checklist. 	The facility has at a minimum taken account of the measures listed.
Inspection And Maintenance			
		BAT is to apply a tool to determine proactive maintenance plans and to develop risk-based inspection plans such as the risk and reliability based maintenance approach; see Section 4.1.2.2.1. Inspection work can be divided into routine inspections, in-service external inspections and out of- service internal inspections and are described in detail in Section 4.1.2.2.2.	Regular maintenance inspections are carried out on all tanks. All tanks are stored above ground

		Location And Layout	
		<p>For building new tanks it is important to select the location and the layout with care, e.g. water protection areas and water catchment areas should be avoided whenever possible. See Section 4.1.2.3.</p> <p>BAT is to locate a tank operating at, or close to, atmospheric pressure aboveground. However, for storing flammable liquids on a site with restricted space, underground tanks can also be considered. For liquefied gases, underground, mounded storage or spheres can be considered, depending on the storage volume.</p>	This will be considered for all future tank installations.
		Tank Colour	
		<p>BAT is to apply either a tank colour with a reflectivity of thermal or light radiation of at least 70 %, or a solar shield on aboveground tanks which contain volatile substances, see Section 4.1.3.6 and 4.1.3.7 respectively.</p>	This will be considered for all future tank installations
		Emissions Minimisation Principle In Tank Storage	
		<p>BAT is to abate emissions from tank storage, transfer and handling that have a significant negative environmental effect, as described in Section 4.1.3.7.</p> <p>This is applicable to large storage facilities allowing a certain time frame for implementation.</p>	N/A
		Monitoring Of VOC	
		<p>On sites where significant VOC emissions are to be expected, BAT includes calculating the VOC emissions regularly. The calculation model may occasionally need to be validated by applying a measurement method. See Section 4.1.2.2.3.</p> <p>There is a split view from three Member States, because in their view, on sites where significant VOC emissions are to be expected (e.g. refineries, petrochemical plants and oil terminals),</p> <p>BAT is to calculate the VOC emissions regularly with validated calculation methods, and because of uncertainties in the calculation methods, emissions from the plants should be monitored occasionally in order to quantify the emissions and</p>	N/A

		<p>to give basic data for refining calculation methods. This can be carried out by using DIAL techniques. The necessity and frequency of emission monitoring needs to be decided on a case-by-case basis.</p> <p>Dedicated systems BAT is to apply dedicated systems; see Section 4.1.4.4. Dedicated systems are generally not applicable on sites where tanks are used for short to medium-term storage of different products.</p>	
	Section 5.1.1.2. Tank specific considerations	Open Top Tanks	
		<p>Open top tanks are used for the storage of, e.g. manure slurry in agricultural premises and water and other non-flammable or non-volatile liquids in industrial facilities, see Section 3.1.1.</p> <p>If emissions to air occur, BAT is to cover the tank by applying:</p> <ul style="list-style-type: none"> • A floating cover, see Section 4.1.3.2 • A flexible or tent cover, see Section 4.1.3.3, or • A rigid cover, see Section 4.1.3.4 <p>Additionally, with an open top tank covered with a flexible, tent or a rigid cover, a vapour treatment installation can be applied to achieve an additional emission reduction, see Section 4.1.3.15. The type of cover and the necessity for applying the vapour treatment system depend on the substances stored and must be decided on a case-by-case basis.</p> <p>To prevent deposition that would call for an additional cleaning step, BAT is to mix the stored substance (e.g. slurry), see Section 4.1.5.1.</p>	N/A
		External Floating Roof Tank	
		<p>External floating roof tanks are used for the storage of, e.g. crude oil; see Section 3.1.2.</p> <p>The BAT associated emission reduction level for a large tank is at least 97 % (compared to a fixed roof tank without measures), which can be achieved when over at least 95 % of</p>	N/A

		<p>the circumference the gap between the roof and the wall is less than 3.2 mm and the seals are liquid mounted, mechanical shoe seals. By installing liquid mounted primary seals and rim mounted secondary seals, a reduction in air emissions of up to 99.5 % (compared to a fixed roof tank without measures) can be achieved. However, the choice of seal is related to reliability, e.g. shoe seals are preferred for longevity and, therefore, for high turnovers. See Section 4.1.3.9.</p> <p>BAT is to apply direct contact floating roofs (double-deck), however, existing non-contact floating roofs (pontoon) are also BAT. See Section 3.1.2.</p> <p>Additional measures to reduce emissions are (see Section 4.1.3.9.2):</p> <ul style="list-style-type: none"> • Applying a float in the slotted guide pole • Applying a sleeve over the slotted guide pole, and/or • Applying 'socks' over the roof legs. <p>A dome can be BAT for adverse weather conditions, such as high winds, rain or snowfall. See Section 4.1.3.5.</p> <p>For liquids containing a high level of particles (e.g. crude oil), BAT is to mix the stored substance to prevent deposition that would call for an additional cleaning step, see Section 4.1.5.1.</p>	
Fixed Roof Tanks			
		<p>Fixed roof tanks are used for the storage of flammable and other liquids, such as oil products and chemicals with all levels of toxicity, see Section 3.1.3.</p> <p>For the storage of volatile substances which are toxic (T), very toxic (T+), or carcinogenic, mutagenic and reproductive toxic (CMR) categories 1 and 2 in a fixed roof tank, BAT is to apply a vapour treatment installation.</p> <p>There is a split view from industry, that this technique is not BAT because in their view:</p> <ol style="list-style-type: none"> a) There is no definition of 'volatile' in this bref 	N/A

		<ul style="list-style-type: none"> b) There is no test of environmental significance c) Products which may be dangerous to the environment, but not classed as toxic, are not captured d) It can be demonstrated that other emission control measures may provide a higher level of environmental protection taking into account the costs and advantages e) Of the various techniques There are no commonly understood performance criteria for a vapour treatment installation this does not take into account the cost, or advantages of other techniques f) This does not provide the flexibility to take into account the technical characteristics of the installation concerned, its geographical location and the local environmental conditions g) There is no proportionality in this conclusion. <p>For other substances, BAT is to apply a vapour treatment installation, or to install an internal floating roof (see Sections 4.1.3.15 and 4.1.3.10 respectively). Direct contact floating roofs and non-contact floating roofs are BAT. In the Netherlands, the condition for when to apply these BAT is when the substance has a vapour pressure (at 20 °C) of 1 kPa and the tank has a volume of 50 m³. In Germany, the condition for when to apply these BAT is when the substance has a vapour pressure (at 20 °C) of 1.3 kPa and the tank has a volume of 300 m³.</p> <p>For tanks < 50 m³, BAT is to apply a pressure relief valve set at the highest possible value consistent with the tank design criteria.</p> <p>The selection of the vapour treatment technology is based on criteria such as cost, toxicity of the product, abatement efficiency, quantities of rest-emissions and possibilities for product or energy recovery, and has to be decided case-by-case. The BAT associated emission reduction is at least 98 % (compared to a fixed roof tank without measures). See Section 4.1.3.15.</p> <p>The achievable emission reduction for a large tank using an internal floating roof is at least 97 % (compared to a fixed roof</p>	
--	--	--	--

		<p>tank without measures), which can be achieved when over at least 95 % of the circumference of the gap between the roof and wall is less than 3.2 mm and the seals are liquid mounted, mechanical shoe seals. By applying liquid mounted primary seals and rim mounted secondary seals, even higher emission reductions can be achieved. However, the smaller the tank and the smaller the number of turnovers the less effective the floating roof is, see Annex 8.22 and Annex 8.23 respectively.</p> <p>Also the case studies in Annex 8.13 show that achievable emission reductions depend on several issues such as the substance that is actually stored, meteorological circumstances, number of turnovers and diameter of the tank. The calculations show that with an internal floating roof an emission reduction in the range 62.9 – 97.6 % can be achieved (compared to a fixed roof tank without measures), where 62.9 % refers to a tank of 100 m³ equipped with only primary seals and 97.6 % refers to a tank of 10263 m³ equipped with primary and secondary seals.</p> <p>For liquids containing a high level of particles (e.g. crude oil) BAT is to mix the stored substance to prevent deposition that would call for an additional cleaning step, see Section 4.1.5.1.</p>	
Atmospheric Horizontal Tanks			
		<p>Atmospheric horizontal tanks are used for the storage of flammable and other liquids, such as oil products and chemicals in all levels of flammability and toxicity, see Section 3.1.4. Horizontal tanks are different to vertical tanks, e.g. since they can inherently operate under higher pressures.</p> <p>For the storage of volatile substances which are toxic (T), very toxic (T+), or CMR categories 1 and 2 in an atmospheric horizontal tank, BAT is to apply a vapour treatment installation.</p> <p>There is a split view from industry, that this technique is not BAT because in their view:</p> <ol style="list-style-type: none"> a) there is no definition of 'volatile' in this brief b) There is no test of environmental significance c) Products which may be dangerous to the 	N/A

		<p>environment, but not classed as toxic, are not captured</p> <p>d) It can be demonstrated that other emission control measures may provide a higher level of environmental protection taking into account the costs and advantages</p> <p>e) Of the various techniques there are no commonly understood performance criteria for a vapour treatment installation</p> <p>f) This does not take into account the costs or advantages of other techniques</p> <p>g) This does not provide the flexibility to take into account the technical characteristics of the installation concerned, its geographical location and the local environmental conditions</p> <p>h) There is no proportionality in this conclusion.</p> <p>For other substances, BAT is to do all, or a combination of the following techniques, depending on the substances stored:</p> <ul style="list-style-type: none"> • Apply pressure vacuum relief • Valves; see Section 4.1.3.11 up to 56 mbar; see Section 4.1.3.11 • Apply vapour balancing; see Section 4.1.3.13 • Apply a vapour holding tank, see Section 4.1.3.14, or • Apply vapour treatment; see Section 4.1.3.15. <p>The selection of the vapour treatment technology has to be decided on a case-by-case basis.</p>	
		Pressurised Storage	
		<p>Pressurised storage is used for storing all categories of liquefied gases, from non-flammable up to flammable and highly toxic. The only significant emissions to air from normal operation are from draining.</p> <p>BAT for draining depends on the tank type, but may be the application of a closed drain system connected to a vapour treatment installation, see Section 4.1.4.</p> <p>The selection of the vapour treatment technology has to be</p>	N/A

		decided on a case-by-case basis.	
		Lifter Roof Tanks	
		<p>For emissions to air, BAT is to (see Sections 3.1.9 and 4.1.3.14):</p> <ul style="list-style-type: none"> • Apply a flexible diaphragm tank equipped with pressure/vacuum relief valves, or • Apply a lifter roof tank equipped with pressure/vacuum relief valves and connected to a vapour treatment installation. <p>The selection of the vapour treatment technology has to be decided on a case-by-case basis.</p>	N/A
		Refrigerated Tanks	
		There are no significant emissions from normal operation, see Section 3.1.10.	Not applicable
		Underground And Mounded Tanks	
		<p>Underground and mounded tanks are used especially for flammable products, see Sections 3.1.11 and 3.1.8 respectively.</p> <p>For the storage of volatile substances which are toxic (T), very toxic (T+), or CMR categories 1 and 2 in an underground or mounded tank, BAT is to apply a vapour treatment installation.</p> <p>There is a split view from industry, that this technique is not BAT because in their view:</p> <ol style="list-style-type: none"> a) There is no definition of 'volatile' in this BREF b) There is no test of environmental significance c) Products which may be dangerous to the environment, but not classed as toxic, are not captured d) It can be demonstrated that other emission control measures may provide a higher level of environmental protection taking into account the costs and advantages of the various techniques e) There are no commonly understood performance criteria for a vapour treatment installation f) This does not take into account the costs or advantages of other techniques 	Not applicable

		<p>g) This does not provide the flexibility to take into account the technical characteristics of the installation concerned, its geographical location and the local environmental conditions</p> <p>h) There is no proportionality in this conclusion.</p> <p>For other substances, BAT is to do all, or a combination, of the following techniques, depending on the substances stored:</p> <ul style="list-style-type: none"> • Apply pressure vacuum relief • Valves; see section 4.1.3.11 • Apply vapour balancing; see section 4.1.3.13 • Apply a vapour holding tank, see Section 4.1.3.14, or • Apply vapour treatment; see Section 4.1.3.15. <p>b) The selection of the vapour treatment technology has to be decided on a case-by-case basis.</p>	
Safety And Risk Management			
	5.1.1.3. Preventing incidents and (major) accidents	<p>The Seveso II Directive (Council Directive 96/82/EC of 9 December 1996 on the control of major accident hazards involving dangerous substances) requires companies to take all measures necessary to prevent and limit the consequences of major accidents. They must, in any case, have a major accident prevention policy (MAPP) and a safety management system to implement the MAPP. Companies holding large quantities of dangerous substances, the so-called upper tiered establishments, must also draw up a safety report and an on-site emergency plan and maintain an up-to-date list of substances. However, plants that do not fall under the scope of the Seveso II Directive can also cause emissions from incidents and accidents. Applying a similar, maybe less detailed, safety management system is the first step in preventing and limiting these.</p> <p>BAT in preventing incidents and accidents is to apply a safety management system as described in Section 4.1.6.1.</p>	<p>The facility is not subject to the Seveso II Directive.</p> <p>O'Toole Composting Ltd will develop, implement and maintain an Accident Prevention and Emergency Response policy and plan in compliance with all relevant health and safety and environmental legislation. This commitment shall be the responsibility of management and employees in all functions.</p>
Operational Procedures And Training			

		BAT is to implement and follow adequate organisational measures and to enable training and instruction of employees for safe and responsible operation of the installation as described in Section 4.1.6.1.1.	Site staff will be trained in accordance with BAT and relevant legislation
		Leakage Due To Corrosion and/or Erosion	
		<p>Corrosion is one of the main causes of equipment failure and can occur both internally and externally on any metal surface, see Section 4.1.6.1.4. BAT is to prevent corrosion by:</p> <ul style="list-style-type: none"> • Selecting construction material that is resistant to the product stored • Applying proper construction Methods • Preventing rainwater or groundwater entering the tank and if necessary, removing water that has accumulated in the tank • Applying rainwater management to bund drainage • Applying preventive maintenance, and where applicable, adding corrosion inhibitors, or applying cathodic protection on the inside of the tank. • Additionally for an underground tank, bat is to apply to the outside of the tank: a corrosion-resistant coating • Plating, and/or • A cathodic protection system. <p>Stress corrosion cracking (scc) is a specific problem for spheres, semi- refrigerated tanks and some fully refrigerated tanks containing ammonia. Bat is to prevent scc by:</p> <ul style="list-style-type: none"> • Stress relieving by post-weld heat treatment, see section 4.1.6.1.4, and • Applying a risk based inspection as • Described in section 4.1.2.2.1. 	The facility design (and the construction/operational phases as appropriate takes account of account of these measures where they are relevant.
		Operational Procedures And Instrumentation To Prevent Overfill	
		<p>BAT is to implement and maintain operational procedures – e.g. by means of a management system – as described in Section 4.1.6.1.5, to ensure that:</p> <ul style="list-style-type: none"> • High level or high pressure instrumentation with alarm 	All potentially polluting substances on site will be stored and transported in accordance with the Environmental Protection Agency “IPC Guidance Note on Storage and Transport.

		<ul style="list-style-type: none"> settings and/or auto closing of valves is installed • Proper operating instructions are applied to prevent overflow during a tank filling operation, and • Sufficient ullage is available to receive a batch filling. <p>A standalone alarm requires manual intervention and appropriate procedures, and automatic valves need to be integrated into the upstream process design to ensure no consequential effects of closure. The type of alarm to be applied has to be decided for every single tank. See Section 4.1.6.1.6.</p>	
		Instrumentation And Automation To Detect Leakage	
		<p>The four different basic techniques that can be used to detect leaks are:</p> <ul style="list-style-type: none"> • Release prevention barrier system • Inventory checks • Acoustic emission method • Soil vapour monitoring. <p>BAT is to apply leak detection on storage tanks containing liquids that can potentially cause soil pollution. The applicability of the different techniques depends on the tank type and is discussed in detail in Section 4.1.6.1.7.</p>	<p>All potentially polluting substances on site will be stored and transported in accordance with the Environmental Protection Agency "IPC Guidance Note on Storage and Transport"</p>
		Risk-Based Approach To Emissions To Soil Below Tanks	
		<p>The risk-based approach to emissions to soil from an aboveground flat-bottom and vertical, storage tank containing liquids with a potency to pollute soil, is that soil protection measures are applied at such a level that there is a 'negligible risk' for soil pollution because of leakage from the tank bottom or from the seal where the bottom and the wall are connected. See Section 4.1.6.1.8 where the approach and the risk levels are explained.</p> <p>BAT is to achieve a 'negligible risk level' of soil pollution from bottom and bottom-wall connections of aboveground storage tanks. However, on a case-by-case basis, situations might be identified where an 'acceptable risk level' is sufficient.</p>	<p>Not applicable</p>
		Soil Protection Around Tanks –Containment	
		<p>BAT for aboveground tanks containing flammable liquids or</p>	<p>All potentially polluting substances on site will be stored</p>

		<p>liquids that pose a risk for significant soil pollution or a significant pollution of adjacent watercourses is to provide secondary containment, such as: tank bunds around single wall tanks; see Section 4.1.6.1.11</p> <ul style="list-style-type: none"> • Double wall tanks; see Section 4.1.6.1.13 • Cup-tanks; see Section 4.1.6.1.14 • Double wall tanks with monitored bottom discharge; see Section 4.1.6.1.15. <p>For building new single walled tanks containing liquids that pose a risk for significant soil pollution or a significant pollution of adjacent watercourses, BAT is to apply a full, impervious, barrier in the bund, see Section 4.1.6.1.10. For existing tanks within a bund, BAT is to apply a risk-based approach, considering the significance of risk from product spillage to the soil, to determine if and which barrier is best applicable. This risk-based approach can also be applied to determine if a partial impervious barrier in a tank bund is sufficient or if the whole bund needs to be equipped with an impervious barrier. See Section 4.1.6.1.11.</p> <p>Impervious barriers include:</p> <ul style="list-style-type: none"> • A flexible membrane, such as HDPE • A clay mat • An asphalt surface • A concrete surface. <p>For chlorinated hydrocarbon solvents (CHC) in single walled tanks, BAT is to apply CHC- proof laminates to concrete barriers (and containments), based on phenolic or furan resins. One form of epoxy resin is also CHCproof. See Section 4.1.6.1.12. BAT for underground and mounded tanks containing products that can potentially cause soil pollution is to:</p> <ul style="list-style-type: none"> • Apply a double walled tank with leak detection, see Section 4.1.6.1.16, or • To apply a single walled tank with secondary containment and • Leak detection, see Section 4.1.6.1.17. 	<p>and transported in accordance with the Environmental Protection Agency "IPC Guidance Note on Storage and Transfer</p> <p>Retention/ bunding will be designed in accordance with the Guidance note to ensure that in the event of a loss in sealing in containment or any relevant component, leaking substances are retained.</p>
		Flammable Areas And Ignition Sources	
		See Section 4.1.6.2.1 together with ATEX Directive 1999/92/EC.	
		Fire Protection	
		The necessity for implementing fire protection measures has to be decided on a case-by-case basis. Fire protection	The following key fire engineering design objectives for the plant are:

		<p>measures can be provided by applying, e.g. (see Section 4.1.6.2.2):</p> <ul style="list-style-type: none"> • Fire resistant claddings or coatings • Firewalls (only for smaller tanks), and/or • Water cooling systems. 	<ul style="list-style-type: none"> • Life safety of occupants • Property protection, insurance requirements and minimising operational disruption • Satisfy relevant Legislation • Hazard identification and risk mitigation • The plant design incorporates the following fire engineering factors to achieve these objectives: • Fire fighting provisions (water supply, dry/wet mains, mechanical hoses) • Fire detection systems • Fire alarm systems • Fire suppression (conventional sprinklers, misting systems, <p>Fire fighting storage tanks and a pumphouse are installed on site. The Accident Prevention and Emergency Response policy and plan will include details of emergency alarm signals, fire evacuation procedures and a firefighting equipment list with locations.</p>
		Fire-Fighting Equipment	
		<p>The necessity for implementing fire-fighting equipment and the decision on which equipment to apply has to be taken on a case-by-case basis in agreement with the local fire brigade. Some examples are given in Section 4.1.6.2.3.</p>	<p>The following key fire engineering design objectives for the plant are:</p> <ul style="list-style-type: none"> • Life safety of occupants • Property protection, insurance requirements and minimising operational disruption • Satisfy relevant Legislation • Hazard identification and risk mitigation • The plant design incorporates the following fire engineering factors to achieve these objectives: • Fire fighting provisions (water supply, dry/wet mains, mechanical hoses) • Fire detection systems • Fire alarm systems • Fire suppression • Fire fighting storage tanks and a pumphouse will be installed on site. The Accident Prevention and Emergency Response policy and plan will include details of emergency alarm signals, fire evacuation procedures and a firefighting equipment list with locations.
		Containment Of Contaminated Extinguishant	

For internal purposes only.
Consent of copyright owner required for any other use.

		<p>The capacity for containing contaminated extinguishant depends on the local circumstances, such as which substances are stored and whether the storage is close to watercourses and/or situated in a water catchment area. The applied containment therefore has to be decided on a case-by-case basis, see Section 4.1.6.2.4.</p> <p>For toxic, carcinogenic or other hazardous substances, BAT is to apply full containment.</p>	<p>The proposed drainage system allows for fire water containment in a detention basin on site. Prior to the detention basin the fire water shall be treated by passage through a class 1 oil interceptor. It will then be transferred to a detention basin prior to removal offsite to an approved facility.</p> <p>O'Toole Composting Ltd will prepare and implement a Fire Water Risk Assessment Report which will document possible contamination of ground, groundwater or surface water from firewater run-off in the event of a fire on site and provisions for containment. The Assessment will be developed with reference to the Environmental Protection Agency's "Fire-Water Retention Facilities (Draft) Guidance note to Industry on the Requirements for Fire-Water Retention Facilities".</p>
Safety And Risk Management			
<p>5.1.2.Storage of packaged dangerous substances</p>		<p>Operational losses do not occur in storing packaged dangerous materials. The only possible emissions are from incidents and (major) accidents.</p> <p>Companies that fall under the scope of the Seveso II Directive are required to take all measures necessary to prevent and limit the consequences of major accidents. They must, in any case have a major accident prevention policy (MAPP) and a safety management system to implement the MAPP.</p> <p>Companies in the high risk category (Annex I of the Directive) must also draw up a safety report and an on-site emergency plan and maintain an up-to-date list of substances. However, companies storing dangerous substances not falling under the scope of the Seveso II Directive can also cause emissions from incidents and accidents.</p> <p>Applying a similar, maybe less detailed, safety management system is the first step in preventing and limiting these.</p> <p>BAT in preventing incidents and accidents are to apply a safety management system as described in Sections 4.1.6.1.</p> <p>The degree of detail of the system is clearly dependent on various factors such as: the quantities of substances stored, specific hazards of the substances and the location of the storage. However, the minimum level of BAT is to assess the risks of accidents and incidents on the site using the five steps described in Section 4.1.6.1</p>	<p>The facility is not subject to the Seveso II Directive.</p> <p>O'Toole Composting Ltd. will develop, implement and maintain an Accident Prevention and Emergency Response policy and plan in compliance with all relevant health and safety and environmental legislation. This commitment shall be the responsibility of management and employees in all functions.</p>

		Training And Responsibility	
		<p>BAT is to appoint a person or persons who is or are responsible for the operation of the store.</p> <p>BAT is to provide the responsible person(s) with specific training and retraining in emergency procedures as described in Section 4.1.7.1 and to inform other staff on the site of the risks of storing packaged dangerous substances and the precautions necessary to safely store substances that have different hazards.</p>	The facility has proposed personnel in line with fit and proper person requirements
		Storage Area	
		<p>BAT is to apply a storage building and/or an outdoor storage area covered with a roof, as described in Section 4.1.7.2. For storing quantities of less than 2500 litres or kilograms dangerous substances, applying a storage cell as described in Section 4.1.7.2 is also BAT.</p>	Not applicable
		Separation And Segregation	
		<p>BAT is to separate the storage area or building of packaged dangerous substances from other storage, from ignition sources and from other buildings on- and off-site by applying a sufficient distance, sometimes in combination with fire-resistant walls. MSs apply different distances between the (outdoor) storage of packaged dangerous substances and other objects on- and off-site; see Section 4.1.7.3 for some examples.</p> <p>BAT is to separate and/or segregate incompatible substances. For the compatible and incompatible combinations see Annex 8.3. MSs apply different distances and/or physical partitioning between the storage of incompatible substances; see Section 4.1.7.4 for some examples.</p>	Not applicable
		Containment Of Leakage And Contaminated Extinguishant	
		<p>BAT is to install a liquid-tight reservoir according to Section 4.1.7.5, that can contain all or a part of the dangerous liquids stored above such a reservoir. The choice whether all or only a part of the leakage needs to be contained depends on the substances stored and on the location of the storage (e.g. in a water catchment area) and can only be decided on a case-by-case basis.</p>	<p>The proposed drainage system allows for fire water containment in a detention basin on site. Prior to the detention basin the fire water shall be treated by passage through a class 1 oil interceptor. It will then be transferred offsite to an approved facility.</p> <p>O'Toole Composting Ltd. will prepare and implement a Fire Water Risk Assessment Report which will document possible contamination of ground, groundwater or</p>

		BAT is to install a liquid-tight extinguishant collecting provision in storage buildings and storage areas according to Section 4.1.7.5. The collecting capacity depends on the substances stored, the amount of substances stored, the type of package used and the applied fire-fighting system and can only be decided on a case-by-case basis	surface water from firewater run-off in the event of a fire on site and provisions for containment. The Assessment will be developed with reference to the Environmental Protection Agency's "Fire-Water Retention Facilities (Draft) Guidance note to Industry on the Requirements for Fire-Water Retention Facilities".
		Preventing Ignition	
		<p>BAT is to apply a suitable protection level of fire prevention and fire-fighting measures as described in Section 4.1.7.6. The appropriate protection level has to be decided on a case-by-case basis in agreement with the local fire brigade.</p> <p>BAT is to prevent ignition at source as described in Section 4.1.7.6.1.</p>	<p>The following key fire engineering design objectives for the plant are:</p> <ul style="list-style-type: none"> • Life safety of occupants • Property protection, insurance requirements and minimising operational disruption • Satisfy relevant Legislation • Hazard identification and risk mitigation • The plant design incorporates the following fire engineering factors to achieve these objectives: • Fire fighting provisions (water supply, dry/wet mains, mechanical hoses) • Fire detection systems • Fire alarm systems • Fire suppression (conventional sprinklers, misting systems,) • Fire fighting storage tanks and a pumphouse are installed on site. The Accident Prevention and Emergency Response policy and plan will include details of emergency alarm signals, fire evacuation procedures and a firefighting equipment list with locations.
5.1.3. Basins and lagoons			
		<p>Basins and lagoons are used for the storage of, e.g. manure slurry in agricultural premises and water and other non-flammable or volatile liquids in industrial facilities. Where emissions to air from normal operation are significant, e.g. with the storage of pig slurry, BAT is to cover basins and lagoons using one of the following options:</p> <ul style="list-style-type: none"> • A plastic cover; see Section 4.1.8.2 • A floating cover; see Section 4.1.8.1, or • Only small basins, a rigid cover; see Section 4.1.8.2. 	N/A

Consent of copyright owner required for any other use.

		<p>Additionally, where a rigid cover is used, a vapour treatment installation can be applied to achieve an extra emission reduction, see Section 4.1.3.15. The need for and type of vapour treatment must be decided on a case-by-case basis.</p> <p>To prevent overflowing due to rainfall in situations where the basin or lagoon is not covered, BAT is to apply a sufficient freeboard, see Section 4.1.11.1.</p> <p>Where substances are stored in a basin or lagoon with a risk of soil contamination, BAT is to apply an impervious barrier. This can be a flexible membrane, a sufficient clay layer or concrete, see Section 4.1.9.1.</p>	
5.1.4. Atmospheric mined caverns		Emissions To Air From Normal Operation	
		Where a number of caverns with a fixed waterbed storing liquid hydrocarbons are present, BAT is to apply vapour balancing, see Section 4.1.12.1. hydrocarbons is, therefore, to apply caverns wherever the site geology is suitable, see Sections 3.1.15 and 4.1.13.3.	Not applicable
		Emissions From Incidents And (Major) Accidents	
		<p>BAT, in preventing incidents and accidents, is to apply a safety management system as described in Section 4.1.6.1.</p> <p>BAT is to apply, and then regularly evaluate, a monitoring programme which at least includes the following (see Section 4.1.13.2):</p> <ul style="list-style-type: none"> • Monitoring of the hydraulic flow pattern around the caverns by means of groundwater measurements, piezometers and/or pressure cells, seepage water flow rate metering • Assessment of cavern stability by seismic monitoring • Water quality follow-up procedures by regular sampling and analysis • Corrosion monitoring, including periodic casing evaluation. <p>For preventing the stored product from escaping out of the</p>	Not applicable

		<p>cavern, BAT is to design the cavern in such a way that at the depth at which it is situated, the hydrostatic pressure of the groundwater surrounding the cavern is always greater than that of the stored product, see Section 4.1.13.5.</p> <p>For preventing seepage water entering the cavern, BAT is, apart from a proper design, to additionally apply cement injection, see Section 4.1.13.6.</p> <p><i>If seepage water that enters the cavern is pumped out, BAT is to apply waste water treatment before discharge, see Section 4.1.13.3.</i></p> <p><i>BAT is to apply automated overflow protection, see Section 4.1.13.8.</i></p>	
		Inspection And Maintenance	
5.2. Transfer and handling of liquids and liquefied gases	5.2.1. General principles to prevent and reduce emissions	BAT is to apply a tool to determine proactive maintenance plans and to develop risk-based inspection plans such as, the risk and reliability based maintenance approach; see Section 4.1.2.	This will be incorporated into the preventative maintenance programme.
		Leak Detection And Repair Programme	
		For large storage facilities, according to the properties of the products stored, BAT is to apply a leak detection and repair programme. Focus needs to be on those situations most likely to cause emissions (such as gas/light liquid, under high pressure and/or temperature duties). See Section 4.2.1.3. This is applicable to large storage facilities, allowing a certain time frame for implementation.	N/A
		Emissions Minimisation Principle In Tank Storage	
		BAT is to abate emissions from tank storage, transfer and handling that have a significant negative environmental effect, as described in Section 4.1.3.1.	N/A
		Safety And Risk Management	
		BAT in preventing incidents and accidents are to apply a safety management system as described in Section 4.1.6.1.	Safety management systems will comply with BAT
		Operational Procedures And Training	
		BAT is to implement and follow adequate organisational measures and to enable the training and instruction of employees for safe and responsible operation of the	Safety management systems will comply with BAT

		installation as described in Section 4.1.6.1.1.	
		5.2.2.1. Piping	
	5.2.2. Considerations on transfer and handling techniques	<ul style="list-style-type: none"> • Fitting blind flanges to infrequently used fittings to prevent accidental opening • Using end caps or plugs on open- ended lines and not valves • Ensuring gaskets are selected appropriate to the process application • Ensuring the gasket is installed • Correctly • Ensuring the flange joint is • Assembled and loaded correctly • Where toxic, carcinogenic or other hazardous substances are transferred, fitting high integrity gaskets, such as spiral wound, kammprofile or ring joints. <p>Internal corrosion may be caused by the corrosive nature of the product being transferred, see Section 4.2.3.1. BAT is to prevent corrosion by</p> <ul style="list-style-type: none"> • Selecting construction material that is resistant to the product • Applying proper construction methods • Applying preventive maintenance, and • Where applicable, applying an internal coating or adding corrosion inhibitors. <p>To prevent the piping from external corrosion, BAT is to apply a one, two, or three layer coating system depending on the site-specific conditions (e.g. close to sea). Coating is normally not applied to plastic or stainless steel pipelines. See Section 4.2.3.2.</p>	Not applicable
		5.2.2.2. Vapour Treatment	
		BAT is to apply vapour balancing or treatment on significant emissions from the loading and unloading of volatile substances to (or from) trucks, barges and ships. The significance of the emission depends on the substance and the volume that is emitted, and has to be decided on a case-by-case basis. For more detail see Section 4.2.8.	Not applicable

		For example, according to Dutch regulations, the emission of methanol is significant when over 500 kg/yr is emitted.	
		5.2.2.3. Valves	
		<p>BAT for valves include:</p> <ul style="list-style-type: none"> • Correct selection of the packing material and construction for the process application • With monitoring, focus on those valves most at risk (such as rising stem control valves in continual operation) • Applying rotating control valves or variable speed pumps instead of rising stem control valves • Where toxic, carcinogenic or other hazardous substances are involved, fit diaphragm, bellows, or double walled valves • Route relief valves back into the transfer or storage system or to a vapour treatment system. See sections 3.2.2.6 and 4.2.9. 	The provision of equipment will be in accordance with BAT
		5.2.2.4. Pumps And Compressors	
		<p>which constitute BAT:</p> <ul style="list-style-type: none"> • Proper fixing of the pump or compressor unit to its base-plate or frame • Having connecting pipe forces within producers' recommendations • Proper design of suction pipework to minimise hydraulic imbalance • Alignment of shaft and casing within producers' recommendations • Alignment of driver/pump or compressor coupling within producers' recommendations when fitted • Correct level of balance of rotating parts • Effective priming of pumps and compressors prior to start-up • Operation of the pump and compressor within producers' recommended performance range (the optimum performance is achieved at its best efficiency point.) • The level of net positive suction head available should always be in excess of the pump or compressor 	The provision and maintenance of equipment will be in accordance with BAT

		<ul style="list-style-type: none"> Regular monitoring and maintenance of both rotating equipment and seal systems, combined with a repair or replacement programme. <p>Sealing system in pumps</p> <p>BAT is to use the correct selection of pump and seal types for the process application, preferably pumps that are technologically designed to be tight such as canned motor pumps, magnetically coupled pumps, pumps with multiple mechanical seals and a quench or buffer system, pumps with multiple mechanical seals and seals dry to the atmosphere, diaphragm pumps or bellow pumps. For more details see Sections 3.2.2.2, 3.2.4.1 and 4.2.9.</p> <p>Sealing systems in compressors</p> <p>BAT for compressors transferring non-toxic gases is to apply gas lubricated mechanical seals. BAT for compressors transferring toxic gases is to apply double seals with a liquid or gas barrier and to purge the process side of the containment seal with an inert buffer gas.</p> <p>In very high pressure services, BAT is to apply a triple tandem seal system. For more detail see Sections 3.2.3 and 4.2.9.13.</p>	
		5.2.2.5. Sampling Connections	
		BAT, for sample points for volatile products, is to apply a ram type sampling valve or a needle valve and a block valve. Where sampling lines require purging, BAT is to apply closed-loop sampling lines. See Section 4.2.9.14.	Not applicable
		5.3.1. Open Storage	
Section 5.3 Storage of Solids		<p>Moderately drift sensitive and wettable material, open storage might be the only option. Examples are the long-term strategic storage of coal and the storage of ores and gypsum.</p> <p>BAT for open storage is to carry out regular or continuous visual inspections to see if dust emissions occur and to check if preventive measures are in good working order. Following the weather forecast by, e.g. using meteorological instruments on site, will help to identify when the moistening of heaps is necessary and will prevent unnecessary use of resources for moistening the open storage. See Section 4.3.3.1.</p>	Not applicable

		<p>BAT for long-term open storage are one, or a proper combination, of the following techniques:</p> <ul style="list-style-type: none"> • Moistening the surface using durable dust-binding substances, see Section 4.3.6.1 • Covering the surface, e.g. With tarpaulins, see Section 4.3.4.4 • Solidification of the surface, see Table 4.13 • Grassing-over of the surface, see Table 4.13. <p>BAT for short-term open storage are one, or a proper combination, of the following techniques:</p> <ul style="list-style-type: none"> • Moistening the surface using durable dust-binding substances, see Section 4.3.6.1 • Moistening the surface with water, • See Sections 4.3.6.1 covering the surface, e.g. With Tarpaulins, see Section 4.3.4.4. <p>Additional measures to reduce dust emissions from both long and short- term open storage are:</p> <ul style="list-style-type: none"> • Placing longitudinal axis of the heap parallel with the prevailing wind • Applying protective plantings, windbreak fences or upwind mounds to lower the wind velocity • Applying only one heap instead of several heaps as far as possible; with two heaps storing the same amount as one, the free surface increases with 26 % • Applying storage with retaining walls reduces the free surface, leading to a reduction of diffuse dust emissions; this reduction is maximised if the wall is placed upwind of the heap placing retaining walls close together. See table 4.13 for more details. 	
	<p>Section 5.3.2 enclosed storage</p>	<p>BAT is to apply enclosed storage by using, for example, silos, bunkers, hoppers and containers. Where silos are not applicable, storage in sheds can be an alternative. This is, e.g. the case if apart from storage, the mixing of batches is needed.</p> <p>BAT for silos is to apply a proper design to provide</p>	<p>All storage is in bunkers in sheds.</p> <p>Odour and dust abatement measures include biofilter and air handler. All doors are kept closed. An air-lock system for vehicle loading and unloading is proposed.</p>

		<p>stability and prevent the silo from collapsing. See Sections 4.3.4.1 and 4.3.4.5.</p> <p>BAT for sheds is to apply proper designed ventilation and filtering systems and to keep the doors closed. See Section 4.3.4.2.</p> <p>BAT is to apply dust abatement and a BAT associated emission level of 1 – 10 mg/m³, depending on the nature/type of substance stored. The type of abatement technique has to be decided on a case-by-case basis. See Section 4.3.7.</p> <p>For a silo containing organic solids, BAT is to apply an explosion resistant silo (see Section 4.3.8.3), equipped with a relief valve that closes rapidly after the explosion to prevent oxygen entering the silo, as described in Section 4.3.8.4. For a silo containing organic solids, BAT is to apply an explosion resistant silo (see Section 4.3.8.3), equipped with a relief valve that closes rapidly after the explosion to prevent oxygen entering the silo, as described in Section 4.3.8.4.</p>	
	5.3.3.Storage of packaged dangerous solids	For details regarding BAT for the storage of packaged dangerous solids, see Section 5.1.2.	Not applicable
Safety And Risk Management			
	5.3.4. Preventing incidents and (major) accidents	<p>The Seveso II Directive (Council Directive 96/82/EC of 9 December 1996 on the control of major accident hazards involving dangerous substances) requires companies to take all measures necessary to prevent and limit the consequences of major accidents. They must in any case have a major accident prevention policy (MAPP) and a safety management system to implement the MAPP. Companies holding large quantities of dangerous substances, so-called upper tiered establishments, must also draw up a safety report and an on-site emergency plan and maintain an up-to-date list of substances. However, plants that do not fall under the scope of the Seveso II Directive can also cause emissions from incidents and accidents. Applying a similar, maybe less detailed, safety management system is the first step in preventing and limiting these.</p> <p>BAT in preventing incidents and accidents is applying a</p>	<p>The facility is not subject to the Seveso II Directive.</p> <p>O'Toole Composting Ltd. will develop, implement and maintain an Accident Prevention and Emergency Response policy and plan in compliance with all relevant health and safety and environmental legislation. This commitment shall be the responsibility of management and employees in all functions.</p>

		safety management system as described in Section 4.1.7.1.	
Section 5.4 Transfer and handling of solids	5.4.1. General approaches to minimise dust from transfer and handling	<p>BAT is to prevent dust dispersion due to loading and unloading activities in the open air, by scheduling the transfer as much as possible when the wind speed is low. However, and taking into account the local situation, this type of measure cannot be generalised to the whole EU and to any situation irrespective of the possible high costs. See Section 4.4.3.1.</p> <p>Discontinuous transport (e.g. shovel or truck) generally generates more dust emissions than continuous transport such as conveyors. BAT is to make transport distances as short as possible and to apply, wherever possible, continuous transport modes. For existing plants, this might be a very expensive measure. See Section 4.4.3.5.1.</p>	<p>Conveyors will be enclosed and fitted with well designed, robust extraction and filtration equipment on conveyor transfer points, to prevent dust emissions.</p> <p>Transport systems will be rationalised to minimise the generation and transport of dust within the site</p> <p>All road surfaces will be impermeable which will facilitate cleaning when necessary On site spraying in dry weather is carried out to minimise dust. A full air handling system including biofilter is on site and will be upgraded in the near future.</p>
Section 5.4 Transfer and handling of solids	5.4.1. General approaches to minimise dust from transfer and handling	<p>BAT is to prevent dust dispersion due to loading and unloading activities in the open air, by scheduling the transfer as much as possible when the wind speed is low. However, and taking into account the local situation, this type of measure cannot be generalised to the whole EU and to any situation irrespective of the possible high costs. See Section 4.4.3.1.</p> <p>Discontinuous transport (e.g. shovel or truck) generally generates more dust emissions than continuous transport such as conveyors. BAT is to make transport distances as short as possible and to apply, wherever possible, continuous transport modes. For existing plants, this might be a very expensive measure. See Section 4.4.3.5.1.</p> <p>When applying a mechanical shovel, BAT is to reduce the drop height and to choose the best position during discharging into a truck; see Section 4.4.3.4.</p> <p>While driving, vehicles might swirl up dust from solids spread on the ground. BAT then is to adjust the speed of vehicles on-site to avoid or minimise dust being swirled up; see Section 4.4.3.5.2.</p> <p>BAT for roads that are used by trucks and cars only, is applying hard surfaces to the roads of, for example, concrete or asphalt, because these can be cleaned easily to avoid dust being swirled up by vehicles, see Section 4.4.3.5.3. However, applying hard surfaces to the roads is not justified when the roads are used just for big shovel vehicles or when a road is temporary.</p>	<p>Conveyors will be enclosed and fitted with well designed, robust extraction and filtration equipment on conveyor transfer points, to prevent dust emissions.</p> <p>Transport systems will be rationalised to minimise the generation and transport of dust within the site</p> <p>All road surfaces will be impermeable which will facilitate cleaning when necessary On site spraying in dry weather is carried out to minimise dust. A full air handling system including biofilter is on site and will be upgraded in the near future.</p> <p>All vehicle tyres and under carriages is washed with a power washer at least once a week and more frequently if required.</p> <p>A speed limit exists on site.</p>

		<p>BAT is to clean roads that are fitted with hard surfaces according to Section 4.4.6.12.</p> <p>Cleaning of vehicle tyres is BAT. The frequency of cleaning and type of cleaning facility applied (see Section 4.4.6.13) has to be decided on a case-by-case basis.</p> <p>Where it neither compromises product quality, plant safety, nor water resources, BAT for loading/unloading drift sensitive, wettable products is to moisten the product as described in Sections 4.4.6.8, 4.4.6.9 and 4.3.6.1. Risk of freezing of the product, risk of slippery situations because of ice forming or wet product on the road and shortage of water are examples when this BAT might not be applicable.</p> <p>For loading/unloading activities, BAT is to minimise the speed of descent and the free fall height of the product; see Sections 4.4.5.6 and 4.4.5.7 respectively. Minimising the speed of descent can be achieved by the following techniques that are BAT:</p> <ul style="list-style-type: none">• Installing baffles inside fill pipes• Applying a loading head at the end of the pipe or tube to regulate the output speed• Applying a cascade (e.g. Cascade tube or hopper)• Applying a minimum slope angle with, e.g. Chutes. <p>To minimise the free fall height of the product, the outlet of the discharger should reach down onto the bottom of the cargo space or onto the material already piled up. Loading techniques that can achieve this, and that are BAT, are:</p> <ul style="list-style-type: none">• Height adjustable fill pipes• Height adjustable fill tubes, and• Height adjustable cascade tubes. <p>These techniques are BAT, except when loading/unloading non drift sensitive products, for which the free fall height is not that critical.</p>	
--	--	---	--

		Optimised discharged hoppers are available and described in Section 4.4.6.7	
		Grabs	
	5.4.2. Considerations on transfer techniques	<p>For applying a grab, BAT is to follow the decision diagram as shown in Section 4.4.3.2 and to leave the grab in the hopper for a sufficient time after the material discharge.</p> <p>BAT for new grabs, is to apply grabs with the following properties (see Section 4.4.5.1):</p> <ul style="list-style-type: none"> • Geometric shape and optimal load capacity • The grab volume is always higher than the volume that is given by the grab curve • The surface is smooth to avoid material adhering, and • A good closure capacity during permanent operation 	<p>The grab is left in the hopper for an appropriate time after discharge of the material. All operators are instructed in this.</p> <p>New grabs will be purchased in accordance with BAT.</p>
		Conveyors And Transfer Chutes	
		<p>For all types of substances, BAT is to design conveyor to conveyor transfer chutes in such a way that spillage is reduced to a minimum. A modelling process is available to generate detail designs for new and existing transfer points. For more details see Section 4.4.5.5.</p> <p>For non or very slightly drift sensitive products (S5) and moderately drift sensitive, wettable products (S4), BAT is to apply an open belt conveyor and additionally, depending on the local circumstances, one or a proper combination of the following techniques:</p> <ul style="list-style-type: none"> • Lateral wind protection, see Section 4.4.6.1 spraying water and jet spraying at the transfer points, see Sections 4.4.6.8 and 4.4.6.9, and/or • Belt cleaning, see Section 4.4.6.10. <p>For highly drift sensitive products (S1 and S2) and moderately drift sensitive, not wettable products (S3) BAT for new situations, is to:</p> <p>apply closed conveyors, or types where the belt itself or a second belt locks the material (see Section 4.4.5.2), such as:</p>	<p>Conveyors will be enclosed and fitted with well designed, robust extraction and filtration equipment on conveyor transfer points, to prevent dust emissions.</p> <p>Transport systems will be rationalised to minimise the generation and transport of dust within the site</p>

		<ul style="list-style-type: none"> • Pneumatic conveyors • Trough chain conveyors • Screw conveyors • Tube belt conveyor • Loop belt conveyor • Double belt conveyor <p>or to apply enclosed conveyor belts without support pulleys (see Section 4.4.5.3), such as:</p> <ul style="list-style-type: none"> • Aerobelt conveyor • Low friction conveyor • Conveyor with diabolos. <p>The type of conveyor depends on the substance to be transported and on the location and has to be decided on a case-by-case basis.</p> <p>For existing conventional conveyors, transporting highly drift sensitive products (S1 and S2) and moderately drift sensitive, not wettable products (S3), BAT is to apply housing; see Section 4.4.6.2. When applying an extraction system, BAT is to filter the outgoing air stream; see Section 4.4.6.4.</p> <p>To reduce energy consumption for conveyor belts (see Section 4.4.5.2), BAT is to apply:</p> <ul style="list-style-type: none"> • A good conveyor design, including idlers and idler spacing • An accurate installation tolerance, and • A belt with low rolling resistance. <p>See Annex 8.4 for the disperseveness classes (S1 – S4) of solid bulk materials.</p>	
--	--	--	--